



PRI Filler/Primer Gun



GTi Topcoat Gun



GTiW Basecoat Gun



SRi Spot Repair - Topcoats



SRiW Spot Repair - Basecoats

Lesonal

		Air Cap No:	310 (Trans-Tech)	110 (Trans-Tech)	115 (HVLP)	210 (Trans-Tech)	No 215 (HVLP)
PRIMERS & SEALERS	2k HS Primer Filler		1.8 mm	Use PRI Gun	Use PRI Gun	0.8 mm	Use SRi
	PRIMER SURFACER						
	2k Washprimer 2k Etch Primer		1.6 mm	Use PRI Gun	Use PRI Gun	0.8 mm	Use SRi
	2k Epoxy Primer 540 2k Filler 540		1.8 mm	Use PRI Gun	Use PRI Gun	0.8 mm	Use SRi
	2K Primer Surfacer		1.8 mm	Use PRI Gun	Use PRI Gun	0.8 mm	Use SRi
	2k Filler 540 wet on wet		Do Not Use	1.4 mm	Use PRI Gun	0.8 mm	Use SRi
WATERBORNE BASECOAT	Basecoat WB		Use GTiW Gun	Use GTiW Gun	1.3 mm	Use SRiW	0.8 mm
SOLVENTBORNE SOLID COLOURS	2k Single Stage Coating 2k Topcoat		Use GTi Gun	1.4 mm	Use GTi Gun	0.8 mm	0.8 mm
CLEARCOATS	2k MS Clearcoat		Use GTi Gun	1.4 mm	Use GTi Gun	0.8 mm	0.8 mm
HIGH SOLIDS CLEARCOATS	2k HS Extra Clearcoat		Use GTi Gun	1.4 mm	Use GTi Gun	0.8 mm	0.8 mm