



PRI Filler/Primer Gun



GTi Topcoat Gun



GTiW Basecoat Gun



SRI Spot Repair - Topcoats



SRIW Spot Repair - Basecoats

		Air Cap No:	310 (Trans-Tech)	110 (Trans-Tech)	115 (HVLP)	210 (Trans-Tech)	No 215 (HVLP)
PRIMERS & SEALERS	Colorbuild (Non Sanding)		Use GTi Gun	1.4 mm	Use GTi Gun	0.8 or 1.0 mm	Use SRI
	Colorbuild (Sanding)		1.8 mm	Use PRi Gun	Use PRi Gun	0.8 or 1.0 mm	Use SRI
BASECOATS	Autowave Basecoat		Do Not Use	1.3 or 1.4 mm	1.3 mm	1.0 mm	0.8 mm
CLEARCOATS	Autoclear LV420 Superior		Do Not Use	1.3 or 1.4 mm	Use GTi Gun	0.8 or 1.0 mm	0.8 mm
	Autoclear UV		Do Not Use	1.3 or 1.4 mm	Use GTi Gun	0.8 or 1.0 mm	0.8 mm